Accessoires

QG40N series configurator 4.0
Configurator **QG40N series configurator 4.0** USB-A M12 5p female



QG40N series configurator	General specifications v20190829
Configurator	For non-permanent usage
Type	Configurator connection tool & software package
Purpose	Configuration of QG40N analog output sensors: Inclinometers, accelerometers and tilt switches
Features	See manual for details
Connection	USB-A (connect to PC) M12 5p female (connect to sensor)
Length	1,5m to USB & 1.5m to sensor
Data rate	USB2.0 (compatible with USB1.1)
Material	PUR/PP & PVC
Software for Windows	XP, 7, 8, 10: Download from www.dis-sensors.com
Temperature range	+5°…+40°C
Humidity	0-80% RH non-condensing
Ingress protection	IP40
Installation disk	No, download from www.dis-sensors.com
Certifications	
UL listed	No
Electrical data	
Interface	USB2.0 (compatible with USB1.1)
External power	Not required, power supply via USB connection
Configurator pins M12 (and wire color)	Pin 1 (brown) : + Supply Voltage Pin 2: (white): Y signal Pin 3 (blue): Gnd Pin 4 (black): X signal Pin 5 (green/yellow): Centering
Order code	12380 QG40N series configurator 4.0
Manual	Download from dis-sensors.com
Breakout Box for open wire sensors	12345 Breakout cable for QG40N configurator

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000